

List of tables

Table 1	
Translation from keyboard to telephone dial pad	6
Table 2	
DDP general purpose switch settings	51
Table 3	73
Table 4	
Network loop codes	77
Table 5	
Typical CNI configurations	207
Table 6	
Option 81C NTND95AA cable connections to 3PE cards	208
Table 7	
Option 81 CNI to 3PE connections—NTND14 cables	209
Table 8	
Extender codes	210
Table 9	
Network loop codes	210
Table 10	
DCH mode and address select switch settings	234
Table 11	
DDCH daughterboard address select switch settings	235
Table 12	
Peripheral signaling card numbers	259

Table 13	
Extender codes	260
Table 14	
Extender codes	265
Table 15	
Peripheral signaling card numbers	267